

Benchtop Polisher for Small & Medium Volume Fiber Terminations



Developed for small and medium production batch applications, **CTC** Portable Fiber Optic Connector Polishers provides the performance required by installation professionals on fiber optic connectors, termini and contacts.

CTC utilizes a unique latched fiber positioning system which is height adjustable for differing ferrule lengths, along with an automatic oscillating polishing movement. A timer control allows for pre-defined polishing sequences to be achieved by the operator.

CTC uses 2" lapping and polishing films, providing maximum value and a lower 'price per connector'. Consumables and films are in stock at ULTRA TEC at all times.

The standard package for the unit incorporates the following items:

- Polisher
- 5 Resilient Polishing Platens
- 12V Converter

ULTRA TEC
MANUFACTURING, INC.

1025 E Chestnut Ave
Santa Ana, CA 92701
Toll Free (US) 1 877 542 0609
Tel: 1 714 542 0608 Fax: 1 714 542 0627
e-mail: info@ultratecusa.com

www.ultratecusa.com

Product Specifications

System Part #	8802.4 – CTC Four Position Polisher
Lap Diameter	2 inches (50mm)
Weight	2.27 kg (5 lbs)
Power Supply	12V convertor
Timer	10 – 120 Seconds

System Accessories

4093.1	Resilient Surface Polishing platen
4026.1	220V AC Adapter

Connector holders

4044.12	ST
4005.12	SC
4011.12	Ferrule (2.5mm)
4011.22	Ferrule (1.25mm)
4011.32	Ferrule (2.0mm)
4013.12	MU
4014.12	FC
4015.12	LC

Lapping & Polishing Films

2200.2	MULTIMODE Polishing Kit
2200.3	SINGLEMODE Polishing Kit

represented in your area by:

ULTRA TEC
MANUFACTURING, INC.

1025 E. Chestnut Ave., Santa Ana, CA 92701
T: 1.714.542.0608
F: 1.714.542.0627
Toll Free (US): 1 877 542 0609

www.ultratecusa.com