

UT.MINIPOL.1

Fiber Polisher

Fiber Polisher for Small Volume Terminations

UT.MINIPOL.1 provides many of the features of larger polishing units in a small benchtop package—perfect for users with small production batches, or operating with a limited budget.

VERSATILITY

All connector types may be prepared by the system, including SC, FC, ST, D4, SMA, bare fibers, PC, and Flat polishes are all accommodated by simple changes of the lap and/or the workholder.

UNIQUE FEATURES

A factory-set reciprocating arm movement rides the rotating lap producing high performance. This produces quality results at a low price.

SCOPE OF USE

UT.MINIPOL.1 allows for use as a retro-polishing machine or as a quick factory-use system whether used singly, or in tandem with other units.

ACCESSORIES

The system can be powered by 110 or 220 VAC converter or by a standard 12V battery. A wide variety of Workholders are available for extending the use of the system at any time.

TOOLS AND CONSUMABLES

ULTRA TEC stocks a wide range of Polishing Films, Papers, Pads and accessories for all polishing applications.



General Specifications

Order Code	8801.1
Lap Diameter	4" (100mm)
Weight	2.2Kg (5 lbs)
Power Supply	12V Converter
Timer	10-120 seconds

Accessories

4026.1	220VAC Adapter
6594.1	Hard Surface Disc
6593.1	Resilient Surface Disc
4030.1	Carrying Case
4027.1	Battery and Charger

ULTRA TEC
MANUFACTURING, INC.

1025 E Chestnut Ave
Santa Ana, CA 92701
Toll Free (US) 1 877 542 0609
Tel: 1 714 542 0608 Fax: 1 714 542 0627
e-mail: info@ultratecusa.com

www.ultratecusa.com